

	797 Gatehouse Lane Columbus, OH 43235	
ViewMate Installation Procedure		Customer Document
DOC-00051	A-1	1/1
Copyright 2018 Automatiq Measurement Systems LLC All Rights Reserved		<b>CONFIDENTIAL</b>

History:  
15 May 18 – A1 Created.

**1. Introduction:**

- 1.1. Purpose:** This procedure describes the process for installing ViewMate from Pentalogix.
- 1.2. Scope:** This procedure is applicable to customers that require a method for viewing Gerber data files.
- 1.3. Key Terms**

- Automatiq                      Automatiq Measurement Systems LLC
- Pentalogix                      Pentalogix Inc

**2. Install and Run ViewMate:** The following are instructions for installing ViewMate and opening Gerber data files.

- 2.1. Download ViewMate Installation Files:** Pentalogix offers a free download for ViewMate.
  - 2.1.1. Request ViewMate Download:** Navigate to the Pentalogix website at [www.pentalogix.com](http://www.pentalogix.com) and then locate the ViewMate download page. Pentalogix requires completing a form to request a ViewMate download.
  - 2.1.2. Download ViewMate Installation File:** After completing the download request form, Pentalogix will redirect to a download page and will send an email with a serial number and a link for a download of the ViewMate installer.
- 2.2. Install ViewMate:** Run the installer executable to install ViewMate.
- 2.3. Run ViewMate:** Run ViewMate. Gerber file layers can now be viewed.